



0331 Tactical Sierra User Guide



Adding Your Armor

Open the flap on the bottom of your plate bags. Stick to the exterior face of the plate bag if needed.

Slide your plates into the plate bag and re-secure the flap using the inside of the plate bag.



Adding Side Plates

Weave your side plate pouches into the cummerbund webbing. Choose whether you prefer your plates to sit inside or outside of the cummerbund. When the pouches are securely attached, tuck the remaining strap back into the webbing and insert your plates.





Cable Control

Your Sierra plate carrier is equipped with a unique cable control system. Between radios, ATAK, hydration, and other communications and data systems, today's warfighter and law enforcement officers require tools that weren't so ubiquitous only a few decades ago.

Today's gear must evolve, and so we have. Your elastane keepers can be used for running cables, hydration tubes, or other items such as chem lights. However you use them, you'll enjoy simplified use and storage of modern combat tools.



Adding Pouches

Your Sierra plate carrier is equipped with a hybrid exterior face capable of accepting pouches, chest rigs/placards, and ID panels. Utilize the included QASM clips, or add your own depending on which buckle system your placard uses.

Utilize the laser-cut webbing panel on the front to attach any MOLLE pouches such as magazines, radio, grenade, or any others you may need.

Built-In Pouches

Your Sierra includes a kangaroo pouch for adding internal magazine, radio, or other pouches designed for internal use on your carrier.

Your Sierra also includes a zippered administrative pouch that can be used for note-taking gear, maps, and other items.





Adjusting Your Cummerbund

Your Sierra carrier is equipped to adjust length and width by changing the positioning and length of your cummerbund and shoulder straps. Your cummerbund may be adjusted to run wider or tighter depending on your fit. For expediency and best fit, it is recommended that you wear your Sierra carrier while someone else adjusts the fit to your ideal settings.

After opening the covering rear flap, untie the shock cord that attaches both pieces of the cummerbund together and to the carrier.



Weave your shock cord in and out of the webbing on the carrier and at your selected size point on the cummerbund.



When you are finished adjusting and weaving your shock cord, secure it with a knot and re-attach the rear flap.






Adjusting Your Shoulders

Your shoulder pads have both adjustable straps and pads so you can move them to the most comfortable and best fit position.

Tighten or loosen your straps until your plates sit at their ideal position on your body. Move your pad points to their most comfortable or useful position and re-attach them.



For more information, please visit
www.0331tacticalgear.com